

Model	Part Description	Part Number	Cost without	With Insurance		
			Insurance	1st off.	2nd. off	3rd. off
ALL	LCD Screen	CGVHX	\$35.95	\$17.98	\$26.96	\$35.95
ALL	AC Adapter	6TFFF	\$16.95	\$8.48	\$12.71	\$16.95
G1 (CB1C13)	Battery (50)	1132N	\$17.95	\$8.98	\$13.46	\$17.95
G1 (CB1C13)	Bezel (No Glass)	DL-CB11-G1-PLASTICBEZEL	\$19.95	\$9.98	\$14.96	\$19.95
G1 (CB1C13)	Bottom Case	VY6KH	\$11.95	\$5.98	\$8.96	\$11.95
G1 (CB1C13)	Camera	FHTVF	\$2.95	\$1.48	\$2.21	\$2.95
G1 (CB1C13)	DC Jack	DD0ZM7AD000	\$4.95	\$2.48	\$3.71	\$4.95
G1 (CB1C13)	Fan	M46X2	\$4.95	\$2.48	\$3.71	\$4.95
G1 (CB1C13)	Hinge Cover	D11G1-HINGECOVER	\$3.95	\$1.98	\$2.96	\$3.95
G1 (CB1C13)	Hinge Left	FBZM7003010	\$2.95	\$1.48	\$2.21	\$2.95
G1 (CB1C13)	Hinge Right	FBZM7004010	\$2.95	\$1.48	\$2.21	\$2.95
G1 (CB1C13)	Keyboard + Touchpad	WR67C	\$42.95	\$21.48	\$32.21	\$42.95
G1 (CB1C13)	LCD Cable	23ZM7LAW110	\$4.95	\$2.48	\$3.71	\$4.95
G1 (CB1C13)	Memory Card Reader	9CKY7	\$4.95	\$2.48	\$3.71	\$4.95
G1 (CB1C13)	Screw Set	DELL11CB1C13-GEN1-SCREWSET	\$4.95	\$2.48	\$3.71	\$4.95
G1 (CB1C13)	Speaker Set	CH8TH	\$4.95	\$2.48	\$3.71	\$4.95
G1 (CB1C13)	Top Cover	56JWV	\$19.95	\$9.98	\$14.96	\$19.95
G1 (CB1C13)	Touch Pad	DL-11G1-TOUCHPAD	\$19.95	\$9.98	\$14.96	\$19.95
G1 (CB1C13)	Wireless Antenna	DQ6E15G4100	\$7.95	\$3.98	\$5.96	\$7.95
G1 (CB1C13)	Wireless Card	K2GW5	\$4.95	\$2.48	\$3.71	\$4.95
G2 (3120)	Battery (43)	XKPD0	\$36.95	\$18.48	\$27.71	\$36.95
G2 (3120)	Bezel	W3TXP	\$17.95	\$8.98	\$13.46	\$17.95
G2 (3120)	Bottom Case	XYH3	\$14.95	\$7.48	\$11.21	\$14.95
G2 (3120)	Camera	F9KGF	\$9.95	\$4.98	\$7.46	\$9.95
G2 (3120)	DC Jack	9F21D	\$4.95	\$2.48	\$3.71	\$4.95
G2 (3120)	Hinge Left	FBZM8003010	\$7.95	\$3.98	\$5.96	\$7.95
G2 (3120)	Hinge Right	FBZM8002010	\$7.95	\$3.98	\$5.96	\$7.95
G2 (3120)	Keyboard + Touchpad	R36YR	\$42.95	\$21.48	\$32.21	\$42.95
G2 (3120)	LCD Cable	R4NXP	\$9.95	\$4.98	\$7.46	\$9.95
G2 (3120)	Screw Set	DELL11-3120-GEN2-SCREWSET	\$4.95	\$2.48	\$3.71	\$4.95
G2 (3120)	Speaker Set	5MXYN	\$4.95	\$2.48	\$3.71	\$4.95
G2 (3120)	System Board	H4WJ5	\$89.95	\$44.98	\$67.46	\$89.95
G2 (3120)	Top Case	60MY1-WITHLVDS/HINGES	\$29.95	\$14.98	\$22.46	\$29.95
G2 (3120)	USB Board	M90DT	\$9.95	\$4.98	\$7.46	\$9.95
G2 (3120)	Wireless Card	GPFNK	\$13.95	\$6.98	\$10.46	\$13.95
G3 (3180)	Audio Board	7YYXC	\$24.95	\$12.48	\$18.71	\$24.95
G3 (3180)	Battery (42)	Y07HK	\$39.95	\$19.98	\$29.96	\$39.95
G3 (3180)	Bezel	0P37K	\$14.95	\$7.48	\$11.21	\$14.95
G3 (3180)	Bottom Case	YJDF3	\$19.95	\$9.98	\$14.96	\$19.95
G3 (3180)	Camera	F08KG-3180	\$4.95	\$2.48	\$3.71	\$4.95
G3 (3180)	DC Port	XNJ46	\$11.95	\$5.98	\$8.96	\$11.95
G3 (3180)	Hinge Cover Set	DELL-3180-HINGECOVERSET	\$9.95	\$4.98	\$7.46	\$9.95
G3 (3180)	Hinge Set	DELL-CB11-3180-HINGESET	\$14.95	\$7.48	\$11.21	\$14.95
G3 (3180)	Keyboard	5XVF4	\$17.95	\$8.98	\$13.46	\$17.95

Model	Part Description	Part Number	Cost without	With Insurance		
			Insurance	1st off.	2nd. off	3rd. off
G3 (3180)	LCD Cable	P1NX2	\$12.95	\$6.48	\$9.71	\$12.95
G3 (3180)	Palmrest	VK0VC	\$22.95	\$11.48	\$17.21	\$22.95
G3 (3180)	Screw Set	CB113180-SCREWS	\$6.95	\$3.48	\$5.21	\$6.95
G3 (3180)	Speaker Set	DW9G6	\$9.95	\$4.98	\$7.46	\$9.95
G3 (3180)	System Board	1TX65	\$99.95	\$49.98	\$74.96	\$99.95
G3 (3180)	Top Cover	5HR53-NO-WIFICABLE	\$19.95	\$9.98	\$14.96	\$19.95
G3 (3180)	Touchpad	DELL11-3180-TP	\$29.95	\$14.98	\$22.46	\$29.95
Prices updated as of 2/01/19						